


synqNet Drive Wiring Diagram

Ordering Information
Lxyy5z5

x : Feedback Options
E-Incremental Encoder
R-Resolver
B-Sine Encoder EnDat

y: Reference interface option
03 - 3/9 amp rms Cont/Peak
06 - 6/18 amp rms Cont/Peak
10 - 10/20 amp rms Cont/Peak

z: Logic power source
5 - Internal logic power
6 - External logic power



WARNING
THE SERVOSTAR CD OPERATES WITH VOLTAGES AS HIGH AS 230 VAC AND 400 VDC. USE CAUTION. REFER INSTALLATION AND TROUBLESHOOTING TO QUALIFIED PERSONNEL ONLY.

WARNING
HIGH VOLTAGE MAY EXIST UP TO 5 MINUTES AFTER INPUT VOLTAGE IS REMOVED.

XMP-SynqNet-xxx-RJ